






Part	Qty	Description	Part Number
А	1	Engine mount tube	031320
В	1	Engine hook	035022
С	1	Engine block	030165-2
D	1	Engine hook retainer ring	030160
E - H	1	Laser cut cardstock sheet	030139
I	1	Laser cut cardstock sheet	030140
J 1-3	3	5.75" (14.6 cm / 14,3 cm) Body tube	031776
К	1	10.75" (27.3 cm / 27,3 cm) Body tube	030374
L	1	17.75" (45.1 cm / 45,1 cm) Body tube	030365
Μ	1	Launch lug	038166
N	1	Plastic tube adapter	066633
0	1	Nose cone insert	072774
Р	1	Nose cone	072773
Q	1	Laser cut sheet	066781
R - U	3	Laser cut sheet	066783
V - Y	2	Laser cut sheet	066782
Z	1	Laser cut sheet	067102
AA	1	Shock cord	038363
BB	1	Shock cord mount	084445
CC	2	Clay	085705
DD	1	Parachute	035802
EE	1	Orange D to E engine spacer	035005
FF		Included with E-H	
	1	Waterslide decal (not shown)	066784


























MISFIRES TAKE THE KEY OUT OF THE CONTROLLER. WAIT ONE MINUTE BEFORE GOING NEAR THE ROCKET. Disconnect the micro-clips and remove the engine. Take the plug and starter out of the engine. A burned starter means the starter tip was not touching engine propellant. Install a new starter; be sure the tip is touching propellant inside the engine. Push the plug in place. Repeat steps under Countdown and Launch.