





Skill Level **ADVANCED**

7320

MODEL ROCKET INSTRUCTIONS

KEEP FOR FUTURE REFERENCE

IMPORTANT: Please record date found on decal and keep for future reference.

READ ALL INSTRUCTIONS. Make sure you have all parts and supplies. Test fit all parts before applying glue. Refer to your glue manufacturer's dry times during build.

SUPPLIES





























FINE Sandpaper

BLOCK

PLASTIC GLUE YELLOW GLUE

MASKING Tape

SOFT LEAD PENCIL


WAX PAPER

PRIMER





030477 Engine mount tube








030162-2 Green engine block




060552 Plastic engine detail
























090051B-7320














090001-7320 Water slide decals











PAINT AND DECALS

PAINT COLORS

Black Paint Orange Paint White Paint

- 1. Spray rocket with white primer, let dry, and sand. Repeat until rocket is smooth.
- 2. Paint entire rocket white.
- 3. Mask off rocket as needed for orange and black paint application.
- 4. Apply decals only after paint is dry.
- 5. Cut decals from sheet, trimming close to edge.
- 6. One at a time, place in warm water until decal curls and begins to relax.
- $\label{eq:continuous} 7. \ \ \text{Remove and position on rocket, sliding decal away from backing material.}$
- 8. Blot with clean paper towel. Let set overnight.
- 9. OPTIONAL: Apply protective clear coat.


180° VIEWS ->

⚠ CAUTION


For safe handling of spray paints, see manufacturer's warnings and follow instructions for use.

NOTE:

Please refer to packaging for suggested paint scheme and/or decal placement.







COUNTDOWN AND LAUNCH NOTE: Always keep the key *OUT* until final countdown. Fully extend your launch controller wire before launching. **KEY MASKING TAPE** Insert key, push down hard. Bulb will light. 4... 3... **2... 1** , Estimated weight: 3.3 oz. (93.6 g) ESTES® LAUNCH SUPPLIES NEEDED (Sold Separately) While holding key down FIRMLY, • Porta-Pad® II Launch Pad press launch button until LIFTOFF! • Electron Beam® Launch Controller • Recovery Wadding • Starters (with engines) • Plugs (with engines) • Estes® Engines: C5-3, C6-3

PRECAUTIONS



NAR SAFETY CODE













NO DRY GRASS OR WEEDS

PRE-LAUNCH CHECK For safety, never launch a damaged rocket. Check the rocket's body, nose cone and fins. Also, check the engine mount, recovery system and launch lug(s). Repair any damage before launching the rocket.

FLYING YOUR ROCKET Choose a large field (500 ft. [152 m] square) free of dry weeds and brown grass. The larger the launch area, the better your chance of recovering your rocket. Launch only with little or no wind and good visibility. Always follow the National Association of Rocketry (NAR) SAFETY CODE (enclosed).

MISFIRES TAKE THE KEY OUT OF THE CONTROLLER. WAIT ONE MINUTE BEFORE GOING NEAR THE ROCKET. Disconnect the micro-clips and remove the engine. Take the plug and starter out of the engine. A burned starter means the starter tip was not touching engine propellant. Install a new starter; be sure the tip is touching propellant inside the engine. Push the plug in place. Repeat steps under Countdown and Launch.

22 PAP

© 2025 Estes Industries, LLC • All Rights Reserved Estes Industries, LLC • 1295 H Street, Penrose, CO 81240-9698 • Made in Guangdong, China