

POLARIS

KIT NO. 1324
SKILL LEVEL 1



PARTS LIST

A	1	Main Body Tube (BT-50W)	30372
B	1	Payload Section Tube (type BT-50S)	30368
C	1	Die Cut Balsa Sheet (BF-L3)	32254
D	1	Plastic Nose Cone (PNC-50Y)	71009
E	1	Balsa Nose Block (NB-50)	70158
F	1	Launch Lug (LL-2B)	38178
G	1	Engine Mount Tube (BT-20J)	30326
H	1	Engine Hook (EH-2)	35025
I	1	Split Ring Adapter (AR-2050S)	80425
J	1	Adapter Ring (AR-2050)	30164
K	1	Mylar Ring (HR-20)	30168
L	1	Screw Eye (SE-2A)	38252
M	1	Parachute (PK-12A)	85564
N	1	Shock Cord (SC-1)	85730
O	1	Shroud Line Cord (SLT-72)	38237
P	6	Tape Discs (TD-3F)	38406
Q	1	Decal (KD-1324)	37503
R	1	Pattern Sheet	82630

IMPORTANT:

Read all instructions before beginning work on your model. Make sure you have all parts and materials. When you are thoroughly familiar with the assembly procedure, begin construction. Check off each step as you complete it. In each step, test-fit the parts together before applying any glue. If some part doesn't fit properly, sand lightly or build up as needed for precision assembly.

In addition to the parts included in this kit you will need scissors, a pencil, a metal-edged ruler, white glue, a sharp model knife (or a single edge razor blade), fine sandpaper, masking tape, sanding sealer, and paint.



A DAMON COMPANY

ESTES INDUSTRIES
PENROSE, COLO. 81240 USA